

FGTP = Front gang tool post

BGTP = Back gang tool post

	Cutters	Size	Position	P03-GDF-416	P03-GDF-516	P03-GDF-519-HF	P03-GDF-519-HF-AP	P03-GDF-520-HF	P03-GDF-616	P03-GDF-616-HF	P03-GDF-719	P03-GDF-816	P03-GDF-816-II	0400-HF191-R00000-5S01	0400-DF160-R00000-3S01	0400-HF200-R00000-6S01	0400-HF200-R00000-5S01	P03-GDF-519-HF-AP
P034H																		
0400-BU000-01(P03-GSC-117-S)	2	8	FGTP		•	•	•	•	•	•	•	•						
0400-TF080-R0000C-2S01	2	8	FGTP		•	•	•	•	•	•	•	•						
0400-TF080-R0000C-4S01	4	8	FGTP		•	•	•	•	•	•	•	•						
0400-ML12-R0000C-3S01	3	ML	FGTP															•
0400-ML12-R0000C-5S01	5	ML	FGTP															•
P03-GTF-118	7	8	FGTP	•	•	•	•	•	•	•	•	•	•					
P03-GTF-018	7	8	BGTP	•	•	•	•	•	•	•	•	•	•					
P036W																		
0400-TF080-R0000C-2S02	2	8	FGTP											•	•	•	•	
0400-TF080-R00000-9S01	9	8	BGTP											•	•	•	•	
0400-ML12-R0000C-3S01	3	ML	FGTP															•
0400-ML12-R0000C-5S01	5	ML	FGTP															•
B012-III / B020-III / B012-V / B020-V																		
0400-TF080-R00000-11S01	11	8	BGTP											•	•	•	•	

*Developement on request