


QTF5118

Machine: CITIZEN Cincom

Type: R04-5F6

Emplacement, N°: Coulisse linéaire

Travail sur: Broche principale


Type de travail:  $n_{\max}$: - [rpm] $i (n_i / n_o)$: 1 / 1

Attachement: □8

Sans refroidissement

Infos:

- Emplacement U48B

QTF5118

Machine: CITIZEN Cincom

Type: R04-5F6

Location, N°: Gangtool

Work on: Main spindle


Type of work:  $n_{\max}$: - [rpm] $i (n_i / n_o)$: 1 / 1

Attachement: □8

Without coolant

Infos:

- Position U48B

QTF5118

Machine: CITIZEN Cincom

Typ: R04-5F6

Position, N°: Vertikalhalter

Arbeit über: Hauptspindel


Arbeitstyp:  $n_{\max}$: - [rpm] $i (n_i / n_o)$: 1 / 1

Befestigung: □8

Ohne Kühlmittel

Infos:

- Stellung U48B

QTF5118

Macchina: CITIZEN Cincom

Tipo: R04-5F6

Posizione, N°: Slitta lineare

Lavoro al: Mandrino principale

Tipo di lavoro:  $n_{\max}$: - [rpm] $i (n_i / n_o)$: 1 / 1

Ataccamento: □8

Senza refrigerante

Informazioni:

- Posizione U48B